



















**Box Contents**

**Contenido de la caja**

**Contenu de la boîte**

**Contenuti della confezione**

**Lieferumfang**

<p><b>A</b></p> 	<p><b>B (3)</b></p>  <p>36" / 91 cm</p>	<p><b>C</b></p> 
<p><b>D (3)</b></p>  <p>24" / 60 cm</p>	<p><b>E</b></p> 	<p><b>F (5)</b></p> 
<p><b>G (4)</b></p> 	<p><b>H (4)</b></p> 	<p><b>I</b></p>  <p>Tom 1 8" / 20 cm</p>
<p><b>J</b></p>  <p>Tom 2 10" / 25 cm</p>	<p><b>K</b></p>  <p>Tom 3 12" / 30 cm</p>	<p><b>L</b></p>  <p>Tom 4 14" / 36 cm</p>
<p><b>M</b></p>  <p>Snare 14" / 36 cm</p>	<p><b>N</b></p>  <p>Hi-Hat (Top) 12" / 30 cm</p>	<p><b>O (3)</b></p>  <p>Crash 14" / 36 cm</p>
<p><b>P</b></p>  <p>Ride 16" / 41 cm</p>	<p><b>Q</b></p>  <p>Kick 14" / 36 cm</p>	<p><b>R</b></p> 

# ALESIS® STRIKE PRO KIT

alesis.com

Manual Version 1.0










Box Contents

Contenu de la boîte

Lieferumfang

Contenido de la caja

Contenuti della confezione

<b>S</b> 	<b>T</b> 	<b>U</b> 
<b>V</b> 	<b>W</b>  Hi-Hat (Bottom) 12" / 30 cm	<b>X</b> 
<b>Y</b> 	<b>Z (4)</b> 	<b>AA</b> 
<b>BB</b> 	<b>CC</b> 	<b>DD</b> 
<b>EE</b> 	<b>FF (2)</b> 	<b>GG (2)</b> 
<b>HH (2)</b>  24" / 60 cm	<p>Items <b>GG</b> and <b>HH</b> will remain unused. They are intended for the regular Strike Kit; they are not necessary for your Strike Pro Kit.</p> <p>Los elementos <b>GG</b> y <b>HH</b> no se utilizan. Están pensadas para el Strike Kit estándar; no son necesarias para su Strike Pro Kit.</p> <p>Les pièces <b>GG</b> et <b>HH</b> resteront inutilisées. Elles sont prévues pour l'ensemble régulier du Strike Kit ; elles ne sont pas nécessaires au Strike Pro Kit.</p> <p>I pezzi <b>GG</b> e <b>HH</b> rimarranno inutilizzati. Servono per lo Strike Kit normale; per lo Strike Pro Kit non sono necessari.</p> <p><b>GG</b> und <b>HH</b> bleiben ungenutzt. Diese sind für das reguläre Strike Kit bestimmt; Ihr Strike Pro Kit benötigt diese Teile nicht.</p>	